

COMPOSTER



MOUNTING ELEMENTS OF PLASTIC COMPOSTER MADE OF TRAPLAST™

- ① Composter board 130 × 30, 1200 mm, 3 pcs

BEST PRACTICE OF MOUNTING COMPOSTER

A flat terrain of 1200 × 1200 mm is needed to build a Traplast™ plastic modular set while no tools or fasteners are necessary. The construction of the whole composter is based on the simple interlocking of the prepared locks (wells) of the two composter boards ①, which together form a right angle. Place two composter boards distant 1200 mm from each other parallel on the ground. These are marked as sides A in the

Figure. Lock them with two other composter boards - see the Figure B. Now the composter chain holds together, and couples of boards ① can be added both on A and B sides as long as the composting boards are available. Job is done and the composter is ready for use.



! When working / assembling, use the protective equipment!